

Super Dome™ BS Model SB Packing Conversion Kit

Convert your cone packed stuffing boxes to Super Dome™ packing

Installation Instructions

1. Remove cap and top follower.
2. Remove 4 pieces of cone packing and bottom alignment ring if applicable. These items will not be used.
NOTE: Instructions included in your Super Dome™ packing and brass rings are to be followed from this point.
3. Install bottom split bronze ring around polished rod with stenciled side down ↓. Install retainer ring around split bronze ring.
4. Next, install Teflon insert ring around the polished rod, then install the Super Dome™ packing carrier around the Teflon insert ring. Position split in Teflon insert ring 180° opposite the split in Super Dome™ packing carrier. Also alternate each carrier split 180° of previous carrier. Do this for all 3 pieces and generously grease. Make sure that the dome side of the Super Dome™ packing is facing down ↓ with threaded eyelet facing up ↑.
5. Install top split bronze ring around polished rod on top of Super Dome™ packing with stenciled side up ↑. Install retainer ring around split bronze ring.
6. Reinstall top follower if applicable and cap.

CAUTION: DO NOT OVERTIGHTEN PACKING

