

- Notes:
  1. DEBURR AND REMOVE ALL SHARP EDGES .015 X 45° UNLESS OTHERWISE NOTED
- 2. PART TO BE FREE OF MACHINE OILS AND METAL CHIPS
- 3. SURFACE "A" MUST BE PARALLEL TO SURFACE "B" WITHIN .015.
- 4. BORE "C" MUST BE PERPENDICULAR TO SURFACES "A" & "B" WITH IN .010, AND TO HINGE PIN WITHIN .020.

